

OPERATING MANUAL

UNCRATING

Carefully remove protective crating so that the machine and parts are not marred, scratched or impaired. In the event of damage in transit, communicate at once with our representative and the transportation company making delivery.

SHORTAGES

Check shipment carefully against the itemized packing list which is included in the parts box. In case of shortages, report them immediately to the representative from whom the machine was purchased indicating parts not received which have been checked on the packing list. Shortages should be reported within ten days.

HOISTING

Do not use chain or cable! Use rope of sufficient strength around overarm. Exercise extreme care when hoisting machine, balancing on rope before raising.

MOUNTING HEAD ON OVERARM ADAPTER

Face on flange should be thoroughly cleaned, as this aligns milling head square with table working surface. Then clean mounting surface of head carefully and place against flange. When two surfaces are contacted, tighten bolts evenly using normal pressure. Care should be taken so as not to apply abnormal pressure since this will cause distortion of the quill housing.

MOUNTING MOTOR

Place belt over bottom step of spindle pulley, then place motor in housing and lower to place, switch being on left hand side.


PLACING AND ADJUSTING BELTS

Release lock nut handle which is the handle on right of belt housing and also handle on left side and adjust V belts to proper driving tension, then tighten both motor clamping handles.

MACHINE IS READY TO OPERATE

If quill and head are to be used in stationary position, quill lock should be applied. Micrometer depth stop scale is graduated in 20ths of an inch, pitch is .050 and nut is graduated in thousands. By utilizing these

Quill Pinion and Overload Clutch Assembly - PARTS LIST




10 Overload Clutch Trip Lever
 16 Spring Cover
 17 Feed Trip Bracket
 18 Clutch Arm Cover
 M-24 Micro Screw Jam Nut
 29 Spindle Locknut Binding Plug
 M-33 Pinion Shaft Hub Sleeve
 36 Quill Stop Knob
 37 Quill Stop Micro. Screw
 38 Micrometer Nut
 39 Reverse Trip Ball Lever
 40 Feed Reverse Trip Plunger
 41 Reverse Trip Ball Lever Screw
 42 Feed Trip Lever
 43 Feed Trip Plunger
 44 Trip Plunger Bushing
 45 Trip Plunger
 46 Feed Trip Plunger Bushing
 47 Cam Rod Sleeve Assembly
 48 Cam Rod
 49 Trip Handle
 51 Overload Clutch Lever Spring Plunger
 M-51 Indicator Rod Screw
 52 Overload Clutch Washer

M-52 Indicator Rod
 53 Clutch Ring
 M-53 Pinion Shaft Hub
 54 Overload Clutch Sleeve
 M-54 Pinion Shaft Hub Handle
 58 Overload Clutch
 59 Overload Clutch Ring
 60 Overload Clutch Worm Gear
 61 Pinion Shaft Worm Gear Spacer
 F-61 Gear Sleeve Nut
 62 Quill Pinion Shaft Bushing
 63 Quill Pinion Shaft
 64 Quill Pinion
 M-89 Clockspring Stud
 148 Pinion Shaft Hub Screw
 150 Outside Clockspring Pin
 151 Trip Lever Pin
 154 Clutch Ring Pin
 255 #10-24 x 3/8 lg. Rd. Head Screws
 256 Compression Spring
 260 3/16 x 3/4 lg. Dowel Pin
 265 1/4-20 x 1 lg. Cap Screw
 266 3/16 x 3/4 lg. Dowel Pin
 267 #10-24 x 1 1/2 lg. Cap Screw

268 1/4-20 x 1/4 lg. S.L. Set Screw
 275 1/4-20 x 1/4 lg. Set Screw
 278 3/8-24 x 5/8 Cap Screw
 279 #6-32 x 3/8 Set Screw
 280 1/8 x 7/16 lg. Dowel Pin
 281 3/16 x 5/8 lg. Dowel Pin
 282 1/8 x 9/16 lg. Roll Pin
 283 Compression Spring
 284 1/4-20 Bakelite Ball Handle
 285 8-32 x 5/8 lg. Rd. Hd. Screw
 286 #3 Woodruff Key
 287 #7 Woodruff Key
 288 #5108-59 Kohinoor Snap Ring
 310 3/16 Steel Ball
 319 5108-62 Waldes Snap Ring
 321 Safety Clutch Spring
 322 Micrometer Scale
 323 6-32 x 1/4 lg. Rd. Hd. Screw
 328 5/8 x .020 x 42 lg. Clock Spring
 330 Compression Spring
 331 5108-37 Kohinoor Snap Ring
 333 Black Ball for M-54

THIS DESIGN APPLIES TO ALL HEADS FROM SERIAL #1200 TO 1750. FOR 1750 & UP, 349 REPLACES 271 & 176 REPLACES 168.




IMKEN BRG'S. USED ON ALL HEADS UP SERIAL #1200. SEE UPPER R.H. CORNER.

BRIDGEPORT MACHINES Inc.	
BRIDGEPORT CONN.	
1HP MILLING ATTACHMENT	
1-25-48	J-200
HALF SIZE	N.W.

Back Gear Transmission Unit

PARTS LIST



- 7 Timing Belt Pulley
- 8 Timing Belt Pulley Flange
- 12 Back Gear Shifter Fork
- 14 Shift Crank
- 72 Splined Gear Hub
- 73 Bull Gear Key
- 74 Spindle Bull Gear
- 76 Pulley Collar
- 77 Oiler Tube
- 78 Oil Plug
- 95 Countershaft
- 96 Countershaft Gear
- 97 Gearshift Plunger
- 152 Backgear Shift Bushing
- 153 Backgear Shift Crank
- 253 Kohinoor #5008-315 Snap Ring

- 254 $3/16$ x $1/2$ lg. Dowel Pins
- 259 #6-32 x $3/8$ lg. Flat Head Screws
- 261 $1/8$ x $7/8$ lg. Roll Pin
- 262 Compression Spring
- 284 $1/4$ -20 Bakelite Ball Handle
- 290 N-08 Special $5/16$ thick Brg. Locknut
- 291 W-08 Lockwasher
- 292 ND #3208 Ball Brgs. #3 Precision
- 294 Wick $1/8$ O.D.
- 295 #1249 Gits Oil Cup
- 299 #9 Woodruff Key
- 300 $5/8$ -18 Hex Jam Nut
- 301 ND #99503 Double Seal Brg. #3 Precision
- 329 E-2 Construction Spec. TB 4B
- 334 $5/16$ x 2" lg. Dowel Pin

Made by

BRIDGEPORT MACHINES, INC.


500 LINDLEY STREET

BRIDGEPORT, CONN., U.S.A.

Sold By

16


V Belt Unit - PARTS LIST



- | | | | |
|-----|--|-----|---|
| 2 | Gear Housing | 254 | $\frac{3}{16}$ x $\frac{1}{2}$ lg. Dowel Pins |
| 3 | Gear Housing Cover | 255 | #10-24 x $\frac{3}{8}$ lg. Rd. Head Screws |
| 5 | Spindle Pulley | 257 | $\frac{5}{16}$ -18 x $\frac{1}{2}$ lg. K.P. Set Screw |
| 6 | Motor Pulley | 258 | Gilmer #3345 Vee Belt |
| 252 | $\frac{5}{16}$ -18 x $\frac{5}{8}$ lg. Socket Cap Screws | | |

Quill Unit - PARTS LIST

SERIAL No. J1200 AND UP




- | | | | |
|----------------|------------------------|------|-----------------------------------|
| 166 | Spindle | 139 | Collet Aligning Screw |
| 169 | Spindle Dirt Shield | 149 | Drawbar Washer |
| 170, 171, 168* | Brg. Spacer | 348* | MM-207 W1 #5 Precision |
| 31 | Drawbar for R-8 collet | 271* | N.D. #5206 Ball Brg. #5 Precision |
| 32 | Drawbar Knob | 272 | N-06 Locknut |
| 167 | Quill | 273 | W-06 Lockwasher |
| 172 | Quill Nosepiece | 275 | 1/4-20 x 1/4 lg. Set Screw |
| 35 | Quill Skirt | 276 | 10-32 x 5/16 lg. Rd. Hd. Screw |

*For Serial No. 1750 and up
 #349 replaces #271 and
 #176 replaces #168


Quill Unit - PARTS LIST

UP TO SERIAL NO. J1200




- | | | | |
|----|------------------------------|-----|-----------------------------------|
| 25 | Spindle | 50 | Locknut Binding Plug |
| 26 | Spindle Dirt Shield | 139 | Collet Aligning Screw |
| 27 | Timken Brg. Spacer | 149 | Drawbar Washer |
| 28 | Spindle Br. Locknut | 270 | #0 Precision Brg. |
| 29 | Spindle Locknut Binding Plug | 271 | N.D. #5206 Ball Brg. #5 Precision |
| 30 | Brg. Shoulder Ring | 272 | N-06 Locknut |
| 31 | Drawbar for R-8 collet | 273 | W-06 Lockwasher |
| 32 | Drawbar Knob | 274 | 3/8-16 x 3/8 K.P. Set Screw |
| 33 | Quill | 275 | 1/4-20 x 1/4 lg. Set Screw |
| 34 | Quill Nosepiece | 276 | 10-32 x 5/16 lg. Rd. Hd. Screw |
| 35 | Quill Skirt | 277 | 1/8 Allen Pip Plug |

Quill Housing Unit - PARTS LIST



1	Quill Housing	97	Gearshift Plunger
14	Shift Crank	129	Worm Gear Cradle Throw-out
M-47	Lock Handle	130	Shift Sleeve
65	Quill Lock Sleeve (Tapped)	261	1/8 x 7/8 lg. Roll Pin
66	Quill Lock Sleeve	262	Compression Spring
67	Quill Lock Bolt	284	1/4-20 Bakelite Ball Handle
68	Quill Housing Lockbolt	289	7/16-14 Hex Nut Hardened (American Std. regular)
69	Quill Housing Lockbolt (Long)	315	#10-24 x 3/8 lg. K. P. Set Screw
70	Vertical Tee Bolt	316	5/16 x 7/8 lg. Dowel Pin
71	Vertical Tee Bolt Washer	317	#10-24 x 1/2 lg. Cap Screws (use 264)
M-72	Quill Housing Lock Bolt Washer		




PART LIST

THE BRIDGEPORT TURRET MILLING MACHINE

BRIDGEPORT MACHINES, INC.
BRIDGEPORT, CONN. U. S. A.

HEAVY DUTY OVERARM
FOR MODEL J 1HF ATTACHMENT




STANDARD OVERARM FOR
MODEL 'M' P & C ATTACHMENTS

J 19

PART LIST
THE BRIDGEPORT TURRET MILL
BRIDGEPORT MACHINES, INC.
BRIDGEPORT, CONN.

STANDARD OVERALL FOR
MODEL "M" P & C ATTACHMENTS



GENERAL SPEED RECOMMENDATIONS

Material to be cut	Feet Per Minute		
	Rough Cut	Rough and Finish	Light and Finish Cut
Cast Iron-Soft-(Under 200 Brinnell)	70	80-90	120
Cast Iron-Med.-(200-300 Brinnell)	55	60-70	90
Cast Iron-Hard-(Over 200 Brinnell)	40	50-60	70
Steel (Chrome Nickel 40-45 Shore)	30	40	50
Steel (Stainless)	60	80	90
Steel (Low Carbon)	80	90	140
Steel (High Carbon)	40	50	70
Bronze (Medium)	90	120	150
Bronze (Hard)	65	90	130
Brass (Hard)	100	150	200
Copper	150	200	300
Duraluminum	400	---	600
Aluminum	600	---	1000

TABLE OF CUTTING SPEEDS AND FEEDS

Feet Per Minute	Revolutions Per Minute										
	15	20	25	30	40	50	60	70	80	90	100
Diameter, Inches											
1/16''	917	1222	1528	1833	2445	3056	3667	4278	4889	5500	6112
1/8''	458	611	764	917	1222	1528	1833	2139	2445	2750	3056
3/16''	306	407	509	611	815	1019	1222	1426	1630	1833	2037
1/4''	229	306	382	458	611	764	917	1070	1375	1375	1528
5/16''	183	244	306	367	489	611	733	856	978	1100	1222
3/8''	153	204	255	306	407	509	611	713	815	917	1019
7/16''	131	175	218	262	349	437	524	611	698	786	873
1/2''	115	153	191	229	306	382	458	535	611	688	764
5/8''	91	122	153	183	244	306	367	428	489	550	611
3/4''	76	102	127	153	204	255	306	357	407	458	509
7/8''	65	87	109	131	175	218	262	306	349	393	437
1 ''	57	76	95	115	153	191	229	267	306	344	382
1 1/8''	50	67	84	102	136	170	204	238	272	306	340
1 1/4''	45	61	76	91	122	153	183	214	244	275	306
1 3/8''	41	55	69	83	111	139	167	194	222	250	278
1 1/2''	38	50	63	76	102	127	153	178	204	229	255
1 5/8''	35	47	58	70	94	118	141	165	188	212	235
1 3/4''	32	43	54	65	87	109	131	153	175	196	218
1 7/8''	30	40	50	61	81	102	122	143	163	183	204
2 ''	28	38	47	57	76	95	115	134	153	172	191

OPERATION

To operate in high speed range, move high low speed clutch control handle to extreme left then put back gear control in OUT position.

Then, if power feed is desired, crank power feed transmission engagement to IN position, (refer back to explanation of controls) and feed reversing knob should be pushed in for down feed and pulled out for up feed.

The next step is to throw feed control lever to left. Power feed is now in operation in high speed range. Feeds can be selected by cranking quill feed selector to desired feeds.

BACK GEAR OR LOW SPEED RANGE

Stop spindle, then move high low speed clutch control to extreme right and also back gear control handle over to IN position.

RECOMMENDATIONS

Use 2, 3, or 4 flute end mills. 8 flute end mills are usually not as satisfactory. When using shell or face mills standard cutter practice should be observed.


Power feed can be used for drilling up to 3/8" diameter drills. Use manual feed for drills larger than 3/8".

Overload clutch is set at factory to hold up to 200 lbs. DOWN pressure on quill, which will accommodate drills up to 3/8" diameter in mild tool steel.

CAUTION: This clutch should not be tampered with in the field.


to have head perfectly square with table as described below, figure A and B.

**TABLE SQUARE
WITH SPINDLE IN PLANE
THROUGH TRANSVERSE AXIS**



TYPE A

**TABLE SQUARE
WITH SPINDLE IN PLANE
THROUGH LONGITUDINAL AXIS**



HEAD AT 0°

TYPE B

For normal milling operations, graduations on turret and overarm are sufficiently accurate.

Note: When indicating, as in figure A, it may be impossible to get a dead zero in back and front of table as machines are fitted to be slightly high in front, usually about .001".

ANGULAR SETTINGS in one plane are achieved by turning the hand wheel which controls the keyed overarm.

POSITION OF OVERARM can be regulated by loosening two bolts on turret and pulling arm in or out to desired position.

CAUTION: Care should be taken to lock overarm securely after setting.

Note: It is recommended that on heavy milling work, head should be kept as close to face of turret as possible, as maximum rigidity is then obtained.

FEED CONTROL LEVER

Engages over-load clutch on pinion shaft when thrown to left and will stay engaged until either quill stop comes in contact with micrometer nut, forcing feed control lever to drop out automatically, or released manually by throwing lever to right.

Note: Feed Control Lever is carefully set at plant to throw out automatically when quill stop goes against micrometer nut or against safety pin in top. However, if this should go out of adjustment it may easily be brought back by regulating the screw located at bottom of tripping rod.

CAUTION: When adjusting the screw, check automatic throw off in both directions; that is with micrometer nut against the quill stop for down position and quill stop against throw out pin for up position.

QUILL FEED HANDLE

May be removed by simply pulling handle off end of shaft. It is recommended that handle be disengaged when using power feed.

QUILL STOP is used to disengage automatic feed in either direction as well as the setting point for working to given depths.

MICROMETER ADJUSTING NUT is used for setting of depths. Each graduation on nut indicates one thousand of depth, it reads directly to scale mounted along side of it. Depths may be obtained by setting micrometer nut in conjunction with quill stop.

QUILL LOCK

This is a positive quill lock to be used when quill is in stationary position such as milling operations. It is recommended that this lock be used whenever quill movement is not desired.

INDICATOR MOUNTING ROD is used for the fastening of an indicator.

LUBRICATION

Do not operate machine until properly lubricated. Lubrication of head is obtained by use of the drip feed method through two oil cups located at right side of belt housing. Oil cup should be filled every 4 hours of running time with light machine oil such as Socony D.T.E. light or equivalent.

SQUARING ATTACHMENT

In case of precision boring or work of that nature, it is necessary

When back gear control lever is moved to IN position and HIGH LOW speed clutch control moved to extreme right then the head is ready for operation in the low speed range (80-325 RPM).

POWER FEED TRANSMISSION ENGAGEMENT CRANK engages power feed worm gear. When lever is in position as indicated in photograph, the power feed worm gear is engaged. To disengage worm gear, pull knob out and crank handle in clockwise or down direction and move to opposite position.

Note: Crank cannot be swung around in counter clockwise direction; however no damage will occur if moved in this direction. To engage the worm a counter clockwise movement is required.

CAUTION: Power feed worm gear may be engaged when spindle is rotating, however it should be engaged gently to avoid damage to worm gear. The worm gear may be disengaged at any time.

IMPORTANT: It is recommended that the Power Feed worm gear be disengaged whenever the power feed is not required. This will avoid unnecessary wear on power feed worm gear.

QUILL FEED SELECTOR

This crank is used for selecting the three feeds; 1.5, 3 and 6 thousandths per revolution. It is shifted by pulling knob out and turning from one position to the other. Feeds are stamped on cover below indentation hole. Feed is more readily engaged when spindle is running.

FEED REVERSING KNOB

Position of this handle depends upon direction of spindle rotation. If boring with right hand cutting tools, pull feed handle towards operator until clutch becomes engaged.

Neutral position is between forward and reverse position. It is recommended that the handle be left in neutral position when not in use.

MANUAL FEED

Reversing clutch knob should be in neutral position and feed control lever engaged. Clockwise rotation of handwheel moves quill down. The Manual Feed Handwheel and the quill feed handle may be disengaged by moving outward about 1/8".

Note: Feed control lever must be engaged in order to use manual feed controls. Manual Feed Handle and Handwheel may be taken off when not in use.

graduations it is possible to work very accurately as far as different depths are concerned. Micrometer nut when in position is locked securely by tightening micrometer lock nut.

OPERATING INSTRUCTIONS

When tightening or loosening the draw bar it is necessary to lock the spindle. To accomplish this, use spindle brake and lock which is located at top of belt housing, turning it either to the right or left until it binds, then raise handle.

Drawbar has 7/16-20 right hand thread and should be tightened with normal amount of pressure using wrench furnished with machine. To loosen collet back off drawbar and if collet does not open immediately give knob on top of drawbar a slight tap. Spindle has non sticking taper and collets should release readily.

SPINDLE BRAKE

Lever can be moved in either direction to stop spindle; however, when locking spindle, lever should be moved to right or left and then raised.

CAUTION: Be certain that the spindle brake is released before starting the motor. This is important as the motor can be damaged if switch is left on with brake in locked position.


REVERSING SWITCH is used to obtain clockwise or counter clockwise rotation of spindle.

Note: Due to back gear construction, when machine is running in low speed range, spindle rotation is opposite to that of high speed range. Therefore forward on your reversing switch becomes reverse switch in low speed range.

HIGH LOW SPEED CLUTCH CONTROL is directly in front of motor. When knob is in position, as shown on picture, clutch is in high speed position. To put clutch into low speed position turn lever to the extreme right. It is necessary to rotate spindle while engaging high speed clutch. This can be accomplished by either turning spindle nose by hand or by turning drawbar knob using wrench, providing drawbar is pulled up tightly.

CAUTION: Do not shift clutch while motor is running.

Back gear control is used in conjunction with the high low speed clutch control; above back gear control handle is stamped IN and OUT. When back gear control handle is in OUT position, which is the position furthest from face of machine, then HIGH LOW speed clutch control should be located as illustrated in photograph. With these controls in position as explained, head is set for operation in high speed range (660-2720 RPM).



- 9 Worm Gear Cradle
- 11 Feed Gear Shifter Fork
- 14 Shift Crank
- 15 Cluster Gear Cover
- 17 Feed Trip Bracket
- M-43 Handwheel Handle
- 97 Gearshift Plunger
- 98 Cluster Gear Shift Crank
- 99 Feed Drive Cluster Gear
- 100 Feed Drive Cluster Gear (Center)
- 101 Feed Drive Cluster Gear (Upper)
- 102 Cluster Gear Key
- 103 Feed Drive Gear
- 104 Cluster Gear Input Shaft
- 105 Feed Driving Gear
- 106 Cluster Gear Shaft
- 107 Cluster Gear Key
- 108 Bevel Gear Bearing
- 109 Bevel Gear Thrust Spacer
- 110 Feed Reverse Bevel Gear (Boston L 148)
- 111 Feed Worm Shaft Thrust Washer
- 112 Feed Reverse Clutch
- 113 Handwheel Clutch Spring Screw

- 114 Feed Worm Shaft Bushing
- 115 Feed Worm Shaft
- 116 Reverse Clutch Rod
- 117 Feed Reverse Knob
- 118 Handwheel Clutch
- 119 Handwheel Bushing
- 120 Handwheel (use M 42 Casting)
- 121 Worm Shaft Key
- 122 Feed Driving Gear Key
- 123 Bevel Pinion Washer
- 124 Feed Worm Gear Shaft Sleeve
- 125 Worm Gear Spacer
- 126 Feed Drive Worm Gear
- 127 Feed Drive Worm Gear Shaft
- 128 Feed Engage Pin
- 135 Cluster Gear Key
- 137 Cluster Gear Key
- 145 Feed Shift Rod
- 146 Feed Reverse Bevel Pinion
- 147 Cluster Gear Shaft Upper Brg.
- 156 Feed Reverse Knob Stud
- 250 1/4-20 x 3/8 lg. K.P. Set Screw
- 251 5/16-18 x 5/16 lg. half dog pt.


- 251 Set Screw
- 254 3/16 x 1/2 lg. Dowel Pins
- 255 #10-24 x 3/8 lg. rd. Head Screws
- 261 1/8 x 7/8 lg. Roll Pin
- 262 Compression Spring
- 280 1/8 x 7/16 lg. Dowel Pin
- 284 1/4-20 Bakelite Ball Handle
- 287 #7 Woodruff Key
- 303 B-66 Torrington Needle Brg.
- 304 3/8-24 Hex Jam Nut
- 305 A-672-4 Oilite Bearing
- 306 3/32 x 5/16 lg. Pin
- 307 Boston Worm #HLVH .110 Dia. x 7/16 lg. Pin
- 308 .110 Dia. x 7/16 lg. Pin
- 309 3/32 x 3/4 lg. Roll Pin
- 310 3/16 Steel Ball
- 311 Compression Spring
- 312 1/4-28 x 5/16 lg. Set Screw
- 319 319-5108-62 Waldes Snap Ring
- 324 Feed Reverse Bevel Gear
- 332 3/8 Star Washer
- 336 Snap Ring 5100-25


H-68 DIAL HOLDER
 H-69 DIAL LOCK NUT (4 REQUIRED)
 H-70 GEARSHAFT CLUTCH INSERT
 H-71 ELEVATING CRANK
 H-75 CROSS FEED SCREW
 H-76 NO. XF-12 GREASE-SEALED BALL BEARINGS (2 PAIRS REQUIRED)
 H-77 CROSS FEED BEARING BRACKET
 H-78 DIAL WITH 200 GRADUATIONS (3 REQUIRED)
 H-79 DIAL HOLDER (3 REQUIRED)
 H-80 BALL CRANK HANDLE (3 REQUIRED)
 H-81 1/2 - 20 JAM NUT (3 REQUIRED)
 H-82 3/8 - 16 x 1 HOLLOW HEAD CAP SCREW (4 REQUIRED)
 H-83 CHIP GUARD
 H-84 NO. 10 - 32 x 5/8 STOP SCREW
 H-85 3/8 - 16 x 3/4 MACHINE SCREW
 H-86 3/8 - 16 HEXAGON NUT
 H-87 KNEE COLUMN GIB
 H-88 GIB SCREW (3 REQUIRED)
 H-89 KNEE LOCKING PLUNGER
 H-90 KNEE LOCKING CAMSHAFT
 H-91 5/16 - 18 x 5/16 DOG POINT SET SCREW
 H-92 5/16 - 18 x 5/16 SET SCREW
 H-93 CAM SHAFT HUB
 H-94 CAM SHAFT HANDLE
 H-95 NO. 1 x 1" TAPER PIN
 H-96 LEFT HAND KNEE-COLUMN WIPER HOLDER
 H-97 RIGHT HAND KNEE-COLUMN WIPER HOLDER
 H-98 1/4 - 20 x 1 HOLLOW HEAD CAP SCREW (2 REQUIRED)
 H-99 FELT WIPER (2 REQUIRED)
 H-100 NO. 1610 ALEMITE FITTING (4 REQUIRED)
 H-103 3/8 - 16 x 1 MACHINE SCREW
 H-104 3/32 x 3/8 PIN
 H-105 SADDLE
 H-106 CROSS FEED NUT
 H-107 3/16 x 3/16 x 2 1/2 KEY (2 REQUIRED)
 H-108 CROSS FEED NUT RETAINING SCREW (2 REQUIRED)
 H-109 NO. 8 - 32 x 3/8 WASHER HEAD SCREW (2 REQUIRED)
 H-110 FEED NUT BRACKET
 H-111 3/8 - 16 x 1 HOLLOW HEAD CAP SCREW (4 REQUIRED)
 H-112 LONGITUDINAL FEED NUT
 H-113 LONGITUDINAL FEED SCREW
 H-114 TABLE
 H-115 LEFT BEARING BRACKET
 H-116 3/8 - 16 x 1 HOLLOW HEAD CAP SCREW (8 REQUIRED)
 H-117 3/16 x 1 DOWEL PINS (6 REQUIRED)
 H-118 RIGHT BEARING BRACKET
 H-119 SADDLE-TABLE GIB
 H-120 TABLE LOCK PLUNGER
 H-121 TABLE LOCK BOLT
 H-122 TABLE LOCK BOLT HANDLE (2 REQUIRED)
 H-123 TABLE STOP BRACKET
 H-124 3/8 - 16 x 1/2 HOLLOW HEAD CAP SCREW (2 REQUIRED)
 H-125 TABLE STOP PIECE (2 REQUIRED)
 H-126 STOP PIECE T-BOLT (2 REQUIRED)
 H-127 13/32 x 3/4 x 1/8 HARDENED CHAMFERED WASHER (2 REQUIRED)
 H-128 3/8 - 16 HEXAGON NUT (2 REQUIRED)
 H-129 SADDLE-KNEE WIPER PLATE (2 REQUIRED)
 H-130 FELT WIPER (4 REQUIRED)
 H-131 SADDLE-KNEE GIB
 H-132 SADDLE LOCK PLUNGER
 H-133 SADDLE LOCK BOLT
 H-134 NO. 1611 ALEMITE FITTING (2 REQUIRED)
 H-135 5/16 - 18 x 5/16 SET SCREW
 H-136 NO. 10 - 32 x 1/2 OVAL HEAD SCREW (6 REQUIRED)
 H-140 1 1/4 OPEN END AND 1 1/16 BOX END WRENCH
 H-141 GREASE GUN

PART LIST--THE BRIDGEPORT TURRET MILLING MACHINE

- 1 COLUMN AND BASE
- 2 ELEVATING SCREW HOUSING
- 3 ELEVATING SCREW NUT
- 4 3/8 - 16 x 1 HOLLOW HEAD CAP SCREW (2 REQUIRED)
- 5 1/4 - 20 x 3/4 HOLLOW HEAD CAP SCREW (3 REQUIRED)
- 6 DOOR
- 7 DOORKNOB
- 8 DOOR LOCKING CAM
- 9 1/4 - 20 x 1/4 SET SCREW
- 10 17/32 x 1 SPACER
- 11 3/16 x 1 1/2 HINGE PIN (2 REQUIRED)
- 12 WOODEN SHELF (2 HALVES)
- 13 TURRET
- 14 OVERARM
- 15 WORM GEAR
- 16 WORM GEAR HOUSING
- 17 5/8 x 5/8 x 4 KEY
- 18 3/16 x 1 PIN
- 19 WORM
- 20 WORM SHAFT
- 21 NO. 9 WOODRUFF KEY
- 22 SPACER
- 23 NO. 203 PP BALL BEARINGS (2 REQUIRED)
- 24 NO. N-03 BEARING LOCKNUT (2 REQUIRED)
- 25 NO. W-03 BEARING LOCK WASHER (2 REQUIRED)
- 26 BEARING COVER (2 REQUIRED)
- 27 HAND WHEEL
- 28 HANDLE (2 REQUIRED)
- 29 3/8 x 16 x 1 1/2 HOLLOW HEAD CAP SCREW (2 REQUIRED)
- 30 OVERARM LOCKING BOLT (2 REQUIRED)
- 31 21/32 x 1 3/16 x 3/16 WASHER
- 32 OVERARM LOCKING BOLT HANDLE (2 REQUIRED)
- 33 BALL VALVE OILER
- 34 TURRET T-BOLT (4 REQUIRED)
- 35 21/32 x 1 3/16 x 3/16 HARDENED, CHAMFERED WASHER (4 REQUIRED)
- 36 5/8 - 11 HARDENED HEXAGON NUT (4 REQUIRED)
- 37 OVERARM ADAPTER
- 38 ADAPTER LOCKING BOLT
- 39 29/32 x 2 x 1/4 WASHER
- 40 ADAPTER LOCK NUT
- 41 3/16 x 1/2 PIN
- 42 ADAPTER INDEXING PLUNGER
- 43 5/16 x 1 1/4 COIL SPRING
- 44 ADAPTER INDEXING PLUNGER SPRING NUT
- 45 KNURLED PLUNGER NUT
- 46 #10 - 32 JAM NUT
- 50 KNEE
- 51 ELEVATING SCREW
- 52 NO. 3606-J GREASE-SEALED BALL BEARING
- 53 BEARING RETAINER RING
- 54 1/4 x 20 x 1/2 HOLLOW HEAD CAP SCREW (3 REQUIRED)
- 55 BEARING BUSHING
- 56 3/16 x 3/16 x 7/8 KEY
- 57 33/64 x 1 x 0.100 WASHER
- 58 1/2 - 20 JAM NUT (2 REQUIRED)
- 59 BEVEL GEAR
- 60 BEVEL PINION
- 61 NO. 7 WOODRUFF KEY
- 62 NO. 77020 GREASE-SEALED BALL BEARINGS (3 REQUIRED)
- 63 GEAR SHAFT
- 64 BEARING CUP
- 65 BEARING RETAINER RING (3 REQUIRED)
- 66 1/4 - 20 x 1/2 HOLLOW HEAD CAP SCREW (9 REQUIRED)
- 67 DIAL WITH 100 GRADUATIONS


No. _____ Using






- | | | | |
|----|-----------------------------|-----|---|
| 13 | Spindle Pulley Brg. Sleeve | 91 | Brake Lock Washer |
| 75 | Spindle Pulley Hub | 92 | Brake Lock & Handle |
| 79 | Spindle Pulley Key | 93 | Brake Lock Pin |
| 80 | Upper Brg. Spacer (Large) | 131 | Motor Locknut |
| 81 | Upper Brg. Spacer (Small) | 132 | Motor Locknut Handle |
| 82 | Brg. Sleeve Locknut | 133 | Motor Mounting Studs |
| 83 | Upper Brg. Locknut | 134 | Motor Mounting Stud Washers |
| 84 | Cam Ring | 256 | Compression Spring |
| 85 | Spindle Clutch Lever | 284 | 1/4-20 Bakelite Ball Handle |
| 86 | Spindle Clutch Cam Ring Pin | 293 | ND #9507 Single Plate Ball Brg. |
| 87 | Brake Block | 297 | W.B. Jones #167-A Ext. Spring (Lindquist) |
| 88 | Brake Ring Screw | 304 | 3/8-24 Hex Jam Nut |
| 89 | Brake Lock Stud | 318 | 3/8 Lockwasher |
| 90 | Brake Pins | | |

STANDARD OVERALL FOR
MODEL "M" P & C ATTACHMENTS



HEAVY DUTY OVERARM
FOR MODEL J 1HF ATTACHMENT




STANDARD OVERARM FOR
MODEL "M" P & C ATTACHMENTS

J 19

PART LIST

THE BRIDGEPORT TURRET MILL
BRIDGEPORT MACHINES, INC.
BRIDGEPORT, CONN.



PART LIST

THE BRIDGEPORT TURRET MILLING MACHINE

BRIDGEPORT MACHINES, INC.
BRIDGEPORT, CONN. U. S. A.

OPERATING MANUAL

UNCRATING

Carefully remove protective crating so that the machine and parts are not marred, scratched or impaired. In the event of damage in transit, communicate at once with our representative and the transportation company making delivery.

SHORTAGES

Check shipment carefully against the itemized packing list which is included in the parts box. In case of shortages, report them immediately to the representative from whom the machine was purchased indicating parts not received which have been checked on the packing list. Shortages should be reported within ten days.

HOISTING

Do not use chain or cable! Use rope of sufficient strength around overarm. Exercise extreme care when hoisting machine, balancing on rope before raising.

MOUNTING HEAD ON OVERARM ADAPTER

Face on flange should be thoroughly cleaned, as this aligns milling head square with table working surface. Then clean mounting surface of head carefully and place against flange. When two surfaces are contacted, tighten bolts evenly using normal pressure. Care should be taken so as not to apply abnormal pressure since this will cause distortion of the quill housing.

MOUNTING MOTOR

Place belt over bottom step of spindle pulley, then place motor in housing and lower to place, switch being on left hand side.

PLACING AND ADJUSTING BELTS

Release lock nut handle which is the handle on right of belt housing and also handle on left side and adjust V belts to proper driving tension, then tighten both motor clamping handles.

MACHINE IS READY TO OPERATE

If quill and head are to be used in stationary position, quill lock should be applied. Micrometer depth stop scale is graduated in 20ths of an inch, pitch is .050 and nut is graduated in thousands. By utilizing these

graduations it is possible to work very accurately as far as different depths are concerned. Micrometer nut when in position is locked securely by tightening micrometer lock nut.

OPERATING INSTRUCTIONS

When tightening or loosening the draw bar it is necessary to lock the spindle. To accomplish this, use spindle brake and lock which is located at top of belt housing, turning it either to the right or left until it binds, then raise handle.

Drawbar has 7/16-20 right hand thread and should be tightened with normal amount of pressure using wrench furnished with machine. To loosen collet back off drawbar and if collet does not open immediately give knob on top of drawbar a slight tap. Spindle has non sticking taper and collets should release readily.

SPINDLE BRAKE

Lever can be moved in either direction to stop spindle; however, when locking spindle, lever should be moved to right or left and then raised.

CAUTION: Be certain that the spindle brake is released before starting the motor. This is important as the motor can be damaged if switch is left on with brake in locked position.

REVERSING SWITCH is used to obtain clockwise or counter clockwise rotation of spindle.

Note: Due to back gear construction, when machine is running in low speed range, spindle rotation is opposite to that of high speed range. Therefore forward on your reversing switch becomes reverse switch in low speed range.

HIGH LOW SPEED CLUTCH CONTROL is directly in front of motor. When knob is in position, as shown on picture, clutch is in high speed position. To put clutch into low speed position turn lever to the extreme right. It is necessary to rotate spindle while engaging high speed clutch. This can be accomplished by either turning spindle nose by hand or by turning drawbar knob using wrench, providing drawbar is pulled up tightly.

CAUTION: Do not shift clutch while motor is running.

Back gear control is used in conjunction with the high low speed clutch control; above back gear control handle is stamped IN and OUT. When back gear control handle is in OUT position, which is the position furthest from face of machine, then HIGH LOW speed clutch control should be located as illustrated in photograph. With these controls in position as explained, head is set for operation in high speed range (660-2720 RPM).

When back gear control lever is moved to IN position and HIGH LOW speed clutch control moved to extreme right then the head is ready for operation in the low speed range (80-325 RPM).

POWER FEED TRANSMISSION ENGAGEMENT CRANK engages power feed worm gear. When lever is in position as indicated in photograph, the power feed worm gear is engaged. To disengage worm gear, pull knob out and crank handle in clockwise or down direction and move to opposite position.

Note: Crank cannot be swung around in counter clockwise direction; however no damage will occur if moved in this direction. To engage the worm a counter clockwise movement is required.

CAUTION: Power feed worm gear may be engaged when spindle is rotating, however it should be engaged gently to avoid damage to worm gear. The worm gear may be disengaged at any time.

IMPORTANT: It is recommended that the Power Feed worm gear be disengaged whenever the power feed is not required. This will avoid unnecessary wear on power feed worm gear.

QUILL FEED SELECTOR

This crank is used for selecting the three feeds; 1.5, 3 and 6 thousandths per revolution. It is shifted by pulling knob out and turning from one position to the other. Feeds are stamped on cover below indentation hole. Feed is more readily engaged when spindle is running.

FEED REVERSING KNOB

Position of this handle depends upon direction of spindle rotation. If boring with right hand cutting tools, pull feed handle towards operator until clutch becomes engaged.

Neutral position is between forward and reverse position. It is recommended that the handle be left in neutral position when not in use.

MANUAL FEED

Reversing clutch knob should be in neutral position and feed control lever engaged. Clockwise rotation of handwheel moves quill down. The Manual Feed Handwheel and the quill feed handle may be disengaged by moving outward about 1/8".

Note: Feed control lever must be engaged in order to use manual feed controls. Manual Feed Handle and Handwheel may be taken off when not in use.

FEED CONTROL LEVER

Engages over-load clutch on pinion shaft when thrown to left and will stay engaged until either quill stop comes in contact with micrometer nut, forcing feed control lever to drop out automatically, or released manually by throwing lever to right.

Note: Feed Control Lever is carefully set at plant to throw out automatically when quill stop goes against micrometer nut or against safety pin in top. However, if this should go out of adjustment it may easily be brought back by regulating the screw located at bottom of tripping rod.

CAUTION: When adjusting the screw, check automatic throw off in both directions; that is with micrometer nut against the quill stop for down position and quill stop against throw out pin for up position.

QUILL FEED HANDLE

May be removed by simply pulling handle off end of shaft. It is recommended that handle be disengaged when using power feed.

QUILL STOP is used to disengage automatic feed in either direction as well as the setting point for working to given depths.

MICROMETER ADJUSTING NUT is used for setting of depths. Each graduation on nut indicates one thousand of depth, it reads directly to scale mounted along side of it. Depths may be obtained by setting micrometer nut in conjunction with quill stop.

QUILL LOCK

This is a positive quill lock to be used when quill is in stationary position such as milling operations. It is recommended that this lock be used whenever quill movement is not desired.

INDICATOR MOUNTING ROD is used for the fastening of an indicator.

LUBRICATION


Do not operate machine until properly lubricated. Lubrication of head is obtained by use of the drip feed method through two oil cups located at right side of belt housing. Oil cup should be filled every 4 hours of running time with light machine oil such as Socony D.T.E. light or equivalent.

SQUARING ATTACHMENT

In case of precision boring or work of that nature, it is necessary


to have head perfectly square with table as described below, figure A and B.

**TABLE SQUARE
WITH SPINDLE IN PLANE
THROUGH TRANSVERSE AXIS**



TYPE A

**TABLE SQUARE
WITH SPINDLE IN PLANE
THROUGH LONGITUDINAL AXIS**



HEAD AT 0°

TYPE B

For normal milling operations, graduations on turret and overarm are sufficiently accurate.

Note: When indicating, as in figure A, it may be impossible to get a dead zero in back and front of table as machines are fitted to be slightly high in front, usually about .001".

ANGULAR SETTINGS in one plane are achieved by turning the hand wheel which controls the keyed overarm.

POSITION OF OVERARM can be regulated by loosening two bolts on turret and pulling arm in or out to desired position.

CAUTION: Care should be taken to lock overarm securely after setting.

Note: It is recommended that on heavy milling work, head should be kept as close to face of turret as possible, as maximum rigidity is then obtained.

OPERATION

To operate in high speed range, move high low speed clutch control handle to extreme left then put back gear control in OUT position.

Then, if power feed is desired, crank power feed transmission engagement to IN position, (refer back to explanation of controls) and feed reversing knob should be pushed in for down feed and pulled out for up feed.

The next step is to throw feed control lever to left. Power feed is now in operation in high speed range. Feeds can be selected by cranking quill feed selector to desired feeds.

BACK GEAR OR LOW SPEED RANGE

Stop spindle, then move high low speed clutch control to extreme right and also back gear control handle over to IN position.

RECOMMENDATIONS

Use 2, 3, or 4 flute end mills. 8 flute end mills are usually not as satisfactory. When using shell or face mills standard cutter practice should be observed.

Power feed can be used for drilling up to 3/8" diameter drills. Use manual feed for drills larger than 3/8".

Overload clutch is set at factory to hold up to 200 lbs. DOWN pressure on quill, which will accommodate drills up to 3/8" diameter in mild tool steel.

CAUTION: This clutch should not be tampered with in the field.

GENERAL SPEED RECOMMENDATIONS

Material to be cut	Feet Per Minute		
	Rough Cut	Rough and Finish	Light and Finish Cut
Cast Iron-Soft-(Under 200 Brinnell)	70	80-90	120
Cast Iron-Med.-(200-300 Brinnell)	55	60-70	90
Cast Iron-Hard-(Over 200 Brinnell)	40	50-60	70
Steel (Chrome Nickel 40-45 Shore)	30	40	50
Steel (Stainless)	60	80	90
Steel (Low Carbon)	80	90	140
Steel (High Carbon)	40	50	70
Bronze (Medium)	90	120	150
Bronze (Hard)	65	90	130
Brass (Hard)	100	150	200
Copper	150	200	300
Duraluminum	400	---	600
Aluminum	600	---	1000

TABLE OF CUTTING SPEEDS AND FEEDS

Feet Per Minute	Revolutions Per Minute											
	15	20	25	30	40	50	60	70	80	90	100	
Diameter, Inches												
1/16''	917	1222	1528	1833	2445	3056	3667	4278	4889	5500	6112	
1/8''	458	611	764	917	1222	1528	1833	2139	2445	2750	3056	
3/16''	306	407	509	611	815	1019	1222	1426	1630	1833	2037	
1/4''	229	306	382	458	611	764	917	1070	1375	1375	1528	
5/16''	183	244	306	367	489	611	733	856	978	1100	1222	
3/8''	153	204	255	306	407	509	611	713	815	917	1019	
7/16''	131	175	218	262	349	437	524	611	698	786	873	
1/2''	115	153	191	229	306	382	458	535	611	688	764	
5/8''	91	122	153	183	244	306	367	428	489	550	611	
3/4''	76	102	127	153	204	255	306	357	407	458	509	
7/8''	65	87	109	131	175	218	262	306	349	393	437	
1 ''	57	76	95	115	153	191	229	267	306	344	382	
1 1/8''	50	67	84	102	136	170	204	238	272	306	340	
1 1/4''	45	61	76	91	122	153	183	214	244	275	306	
1 3/8''	41	55	69	83	111	139	167	194	222	250	278	
1 1/2''	38	50	63	76	102	127	153	178	204	229	255	
1 5/8''	35	47	58	70	94	118	141	165	188	212	235	
1 3/4''	32	43	54	65	87	109	131	153	175	196	218	
1 7/8''	30	40	50	61	81	102	122	143	163	183	204	
2 ''	28	38	47	57	76	95	115	134	153	172	191	